


END BARS

End bars are needed for proper frame sizing to the sensor Field Of View (FOV). These can be utilized in a variety of configurations.




116-0521

List \$242

Part# 116-0521

200mm (7in) length cross bar. Adjustment length 85mm (3in).



116-0524

List \$286

Part# 116-0524

325mm (12in) length cross bar. Adjustment length 210mm (8in).



116-0512


List \$508

Part# 116-0512

455mm (18in) length cross bar. Adjustment length 340mm (13in).

END BARS

End bars are needed for proper frame sizing to the sensor Field Of View (FOV). These can be utilized in a variety of configurations.



Part# 116-0508

660mm (26in) length cross bar.
Adjustment length 545mm (21in).

116-0508

List \$576

Part# 116-0514

985mm (38in) length cross bar.
Adjustment length 870mm (34in).

116-0514

List \$660

Part# 116-0500

Need a custom length? Call us today for custom size pricing.

116-0500

List \$Call